





The illustration above displays the wall mounting arrangement for the CC 8 loudspeaker and identifies the essential hardware supplied.

Components

- Loudspeaker Mount BCA-I
 - Anchor Bolts M8
- CC 8 Loudspeaker

CC 8 Wall Mounting



BCA-I
Clamp Assembly

How to mount the Loudspeaker?

- o Position BCA-I flat against the wall surface and mark the space for the bolts.
- o Insert the anchor bolts and tighten the mounts to wall
- o Remove the bolts from behind the cabinet and tighten it to the other end of the BCA I clamp.
- o To give space between the wall and the cabinet add BCA-U-LR and BCA-U-SM.

Caution: As the load is dynamic ensure the Loudspeaker is not mounted to any surface where the anchor bolts may get loose in the wall. This could result in a major accident.

This configuration ensures a stable, secure, and standards-compliant wall mounting for the CC 8 loudspeaker, showing all hardware placement and component relationships clearly.